

Installation Reminders:

- 1) Check each panel for defects prior to assembly and do not use any panels with obvious defects.
- 2) Expansion gaps and transition molding is required in all doorways, openings, and spans greater than 26 linear feet.
- 3) Do not use underlayment pad with flooring that already has a pre-attached underlayment pad.

